Formax Atlas C200 High-Speed Automatic Creaser

Instruction Manual



Call Us at 1-800-944-4573



Atlas C200 Auto-Feed High-Speed Creaser

> OPERATOR MANUAL First Edition

INDEX

INTRODUCTION Á	PAGE	3
SAFETY Do's & Don'ts		4
THE ATLAS C200 Labeled Photograph		6
THE CONTROLS The switch panel Features on the switch panel		7 7
QUICK START GUIDE		9
OPERATING Setting the machine Programming the machine Reading stored programmes Paper jamming		20 26 27 29
THE STACKER ASSEMBLY Setting the Stacker unit		30
PERFORATING Equipment, spares Setting the machine		32 33
THE BLADE ASSEMBLY Setting the blade pressure Setting the blade alignment		35 36
REPLACING CREASING BLADE SETS Installing new blade sets Spares		37 39
TROUBLE SHOOTING DISPATCH KIT ACCESSORIES & OPTIONS RECOMMENDED SPARES FUSE POSITIONS AND RATINGS PRODUCT RECYCLING AND DISPOSAL		40 48 49 50 52 53

Á/h^ÁŒ a fully automatic suction feeding creasing system designed for use with both conventional litho and digital printers.

The crease is programmed from the leading edge of the sheet using the controls on the front panel.

The blade and anvil are mechanically controlled over their entire length and can be adjusted to accommodate various weights of media.

IMPORTANT

The operating environment should be controlled to a temperature between 16° C and 27° C Maximum


Specification

Feeding SystemBottom suction feed							
Max. Sheet Size							
500mm (35.4" x 19.7") with Optional							
extension table].							
Min. Sheet Size (in automatic mode)							
Max. Paper Thickness							
type of fold, and substrate)							
Max. No. Creases per Sheet							
Min. Distance Between Creases0.1mm							
Max. No. Stored Programmes Unlimited							
Min. Crease Distance from Leading Edge 2.5mm							
Min. Crease Distance from Tail Edge							
In Hand Feed Mode up to 2499.9mm to Last Crease can be Programmed.							
Speed per Hour (A4 in half)8500							
Speed per Hour (A5 in half)							
Dimensions							
L: (59") H: (48.2") W: (26.8")							
Weight							
Power Requirement							
1phase 220v 60Hz Sound Power Level							
*As part of our continued product improvement plan, specifications and information							
published in this manual are subject to change without notice.							
All specifications are dependent on application, type of stock, temperature, RH and print							
engine used.							
Specifications quoted were measured on uncoated and unprinted stock. E & OE.							

<u>Safety Do's & Don'ts</u> <u>REGLES DE SECURITE : « A FAIRE » ET « A NE PAS FAIRE »</u>							
Do - read this operator manual fully before operating the machine. Lire ce mode d'emploi avant d'utiliser la machine.							
Do - operate with the designated AC current only. Use an exclusive outlet, as overloading may cause fire or an electric shock. Respecter l'alimentation électrique indiquée. Brancher sur une prise séparée car une surcharge peut entraîner un incendie ou un choc électrique.							
Do - install the power cord out of the way to avoid a tripping hazard. Installer le cordon d'alimentation de manière à ne pas pouvoir trébucher par dessus.							
Do - make sure that the mains inlet connector is always easily accessible. <i>Ménager un accès libre à la prise de courant.</i>							
Do not - install the machine in an unstable place such that it tilts or shakes. Ne pas installer la machine sur une surface non plane, afin d'éviter qu'elle ne penche ou ne vibre.							
Do not - unplug the plug or unplug the power cord from the outlet with a wet hand, this can cause an electric shock. Ne pas installer la machine sur une surface non plane, afin d'éviter qu'elle ne penche ou ne vibre.							
Do not - unscrew and remove any covers from the machine, as it can cause an electric shock or injury. Ne démonter et enlever aucun carter de la machine, par crainte de décharge électrique ou de blessure.							
Do not - place receptacles containing liquids on any surface. Ne pas placer de récipient contenant un liquide sur la machine.							
Do not - adjust any part of the machine whilst rollers are running N'effectuer aucun réglage pendant que les rouleaux fonctionnent.							
Do not - operate the machine with loose or trailing clothing or loose hair. Ne pas porter de vêtements flottants et rassembler les cheveux longs lors de l'utilisation de la machine.							
Do not - under any circumstances adjust the paper gate when the machine is switched on. En aucune circonstance, régler le séparateur de papier lorsque la machine est branchée.							

Warning Labels							
Do - be aware of any finger traps and rotating parts when operating the machine. <i>Attention au risque de se coincer les doigts, et aux pièces en mouvement lors du fonctionnement de la machine.</i>							
Do - read this operator manual fully before operating the machine. Lire ce mode d'emploi avant d'utiliser la machine.							
Do not - operate the machine with loose or trailing clothing. Ne pas porter de vêtements flottants lors de l'utilisation de la machine							
Do not - operate the machine with loose hair. Rassembler les cheveux longs lors de l'utilisation de la machine.							
Do - be aware of any finger traps and rotating parts when operating the machine. <i>Attention au risque de se coincer les doigts, et aux pièces en mouvement lors du fonctionnement de la machine.</i>							
Do - be aware of sharp points and blades. Attention aux éléments tranchants et aux couteaux.							
Do - be aware of rotating rollers. <i>Attention aux rouleaux en fonctionnement</i>							
Do - be aware of low current anti-static shock. Attention aux faibles chocs d'électricité statique							


SYSTEM



Page 6

THE SWITCH PANEL

The Switch Panel houses the Compressor switch, System switch, and an industry standard Emergency Stop switch which will stop all power going to the machine when activated.




Features on the Switch Panel

System switch

When activated the system switch will operate the motors in order to begin the creasing sequence.

Compressor switch

Allows the operator to switch off the compressor unit in order to utilise the machine to manually feed sheets.



Setting the machine to operate in automatic sheet feed mode

- 1. Set the gap between the paper gate and the vacuum roller to approximately twice the thickness of the stock to be creased.
- 2. Place the stock to be creased onto the loading table against the fixed side lay.
- 3. Release the clamps on the adjustable side lay and slide up to the paper stack allowing a gap of approximately 0.5mm (1/64 inch) between the paper and the side lay.
- 4. Position the backstop and slide it up to the paper stack, also allowing a gap (as stated in the above step).
- 5. Turn the Emergency Stop button clockwise to switch the power on. After the system start up procedure the touch screen will be displayed as shown below.



IMPORTANT.

If you have not been trained to operate this machine, we strongly advise that you select the red cross icon.


We recommend that you either seek training or ask a trained operator to run the machine for you.

Select the green tick icon only if you have been trained to operate this machine.

If you have not been trained to operate this machine and you select the green tick icon,Á Ø[{ ætAaccept no responsibility for personal injury, damage to the machine or damage to materials being processed by the machine.

WARNING:-


Wait at least 10 seconds, after making any selection on the Touchscreen panel, before switching the machine OFF. Failure to do so could result in the data storage being corrupted, and the machine not operating.




Page 10

CREASING


Quick Start Guide







Page 12

CREASING




SYSTEM







Quick Start Guide



The Status Screen will on occasions be replaced with an Input Calculator Screen as shown below.



Quick Start Guide



Page 18

Touch Screen Calibration.


1. Switch the mains power on and wait for the main screen to appear before commencing to check the horizontal and vertical position of the display. The position of the display within the surround is achieved by operating the button at the rear of the housing, press this a number of times to obtain the correct orientation required, move to the next button to move the position to centralize horizontal. -= = == mm UP Display (Increase value) ON/OFF) DOWN AV / Display (Decrease value) Channel Brightness Contrast Horizontal Vertical 2. (i) Select the tools menu tab, and then Select the Touch Screen calibration icon. (ii) Using a plastic pointer, soft leaded pencil, biro cap etc. and with gentle pressure. Touch the centre of the cross in each corner of the Touch Screen, as prompted, by the hand graphics. This procedure will calibrate the Touch Screen.

Setting the Machine

Adjusting the Paper Gate


Set the height of the Paper Gate to approximately two thicknesses of paper, by turning the disc j. An excessive gap is a most likely cause of double sheet feeding.

This setting is only intended as a guide, for instance, sheets with an upward curl will require this setting to be increased.



Setting the Suction Slot

The suction slot is located inside the vacuum roller and can be adjusted by releasing and moving the suction knob horizontally in either direction to the required position. For light stocks set the knob to the left and for heavier stocks set the knob to the right.



Setting the Adjustable Side Lay

Place the paper stack on to the loading table and slide up to the fixed side lay and paper gate. Release the clamps located at each end of the side lay and slide up towards the paper stack as demonstrated in fig 8.1. Allow a gap of approximately 0.5mm (1/64 inch) between the paper and the side lay.

Setting the Back Stop


Position the backstop and slide up towards the paper stack allowing a gap (as specified in the above step).

Setting the Air Distribution

Depending on the length of the sheet to be creased, the air distribution knob can be rotated to various positions in order to supply air to different ports. Position 2 is recommended for most sheet sizes. However, a better result may be obtained by using the settings below or by experimentation.

Position 1 - For sheets longer than A3 (17") in order to supply air to the centre of the stack, ports 2, 3 and 4 open.

- **2** For A5 sheets or 8 inches long, ports 1 and 2 open.
- 3 For A4 sheets or 11 inches long, ports 1 and 3 open.
- 4 For A3 sheets or 17 inches long, ports 1 and 4 open.
- 5 For sheets longer than A3 (17") in order to supply air to the ends of the stack, ports 1 and 5 open.
- For sheets longer than A3 (17") in order to supply air evenly along the stack ports 1, 3 and 5 open.



Setting the Air Separation Pressure

To control the amount of air supplied to the ports, the air separation knob can be rotated clockwise to decrease the pressure or anti-clockwise to increase the pressure.

Setting the Roller Tilt Mechanism

The roller tilt mechanism has been designed to compensate for when the creasing position on the sheet is not square. This could be due to an inaccuracy in the media or if the roller tilt mechanism has been incorrectly set. The mechanism will be set to zero (square) when the machine is supplied.

To set the mechanism, unlock the roller tilt knob located below the roller tilting handle by turning anti-clockwise. Move the roller tilt handle left or right in order to compensate for any inaccuracy. When the position is set, ensure to lock the roller tilt knob before operating the machine. Repeat the above procedure until the creasing position is square.

Setting the positions of drive wheels and hubs

It is important that the drive wheels and drive hubs on the roller shafts are arranged evenly across the width of the media being creased. This is done to ensure that the media is accurately driven and supported through the rollers.

The drive wheels and hubs are fixed to the rollers by means of a grub screw. To locate this grub screw the rollers can be rotated by operating the motor manually.

DO NOT ROTATE THE DRIVE ROLLERS BY HAND.

To operate the motors manually, switch the machine 'on' at the Emergency Stop switch.

Select the Tools tab that shown below.

nm-inch

at the bottom of the touch screen, the display will change to

1

Inch paper in direction of arrow to clear jams


Press the system switch down and then select the right or left arrows, to rotate the rollers in short pulses.

Lift the exit guard to see if the grub screws in the drive wheels and hubs can be seen. If the grub screws cannot be seen, lower the exit guard and rotate the rollers by selecting the right or left arrows. Loosen the drive wheels and hubs with a 2mm allen key. Arrange the drive wheels and hubs as shown in FIG 10.1. In order to avoid marking on some types of media ensure a gap between the drive wheels and hubs.

This procedure should be repeated when installing perforating blades and anvils onto the drive wheels and hubs.

Inch paper in direction


of arrow to clear jams



Set Feed

The length of suction on the sheet of paper being fed can be adjusted by setting the feed type as follows:-

Select 1 for short suck, select 2 for continuous suck (stream feeding).



NOTES.

- 1. Stream Feed will give the quickest through put of stock through the machine.
- 2. When the first crease is less than 37mm from the leading edge of the paper the feed will be noticeably slower when using speeds 2 and 3.
- 3. When the first crease is less than 50mm from the leading edge of the paper the feed will be noticeably slower when using speed 3.


Setting the infeed roller gap set

The gap between the infeed rollers must be adjusted to suit the stock being used. The gap set can be adjusted as follows:-


- 1. Place a sample sheet of the stock to be used onto the feed bed.
- 2. Select the Tools tab ______ at the bottom of the touch screen, the display will change to that shown below.




- 3. Press the system switch down and then select the left arrow on the touch screen, to rotate the rollers in short pulses until the sheet is gripped in the infeed rollers..
- 4. Test the grip of the sheet in the rollers by trying to remove the sheet by hand, the sheet should be lightly gripped by the rollers. If the grip on the sheet is too light or too heavy it can be adjusted as follows:-
 - (i) Turn the gap set locking knob anti-clockwise to unlock.
 - (ii) Move the gap set lever up to increase the gap or down to decrease the gap.
 - (iii) Turn the gap set locking knob clockwise to lock.








Page 26




SYSTEM

Jobs matching characters in text box will be shown in this area - selecting job from this area will show job settings in the right hand status area. Job selected will be shown in text box.





Loading job confirmation screen.



The loaded job can be run or modified and saved as the same job name.

Overwrite job confirmation screen.





Running the machine

Run the job as described on page 13. The machine will complete its creasing operation if a sheet has already been fed through the paper gate.

Paper jamming

In the event of a paper jam occurring whilst the machine is operating, select the Tools

tab

at the bottom of the touch screen, the display will change to that shown

below. Press the system switch down and then select the right or left arrows, to inch the paper forwards or backwards.



Setting the machine to operate in manual sheet feed mode

In order to feed heavy stock, very small or very large sheets, embossed or even irregular shaped sheets, it may be necessary to feed the sheets manually. The machine can be programmed and set up in exactly the same way as explained when operating the machine automatically. However, the paper gate must be raised to its highest position for the sheets to be fed freely. Operating the machine in manual sheet feed mode will also require the suction length to be continuous in order to accommodate various types of stock. Therefore, the feed should be set to Stream Feed (Vacuum Drum position 2) see page 10. The machine can now be started by activating the System switch to 'on'. Do not activate the Compressor switch.

Select the

icon on the touch screen and begin to slide the sheets individually through

the paper gate until they are driven by the drive belts.

System Switch off.

To stop feeding the sheets, select the **()** icon on the touch screen and switch the



The stacker unit on the machine is used to catch the sheets once they have been creased or perforated.

Setting the Stacker assembly


1. Assemble the stacker unit to the machine as shown in fig 13.1 below.

Important

Ensure that the stacker unit has been assembled to the machine properly. However, if it has not, the connection on the magnetic switch will be broken and the machine will not operate (see Trouble shooting pages for details).

There are two side guides on the stacker unit; a left handed (fixed) guide and a right handed (movable) guide held on by a magnetic strip. There is also a left hand extension guide. The guides will control the way in which the paper is collated by setting their positions on the stacker bed.

- 2. Place a single sheet (from the stack to be creased / perforated) on to the stacker bed against the fixed 'left hand' guide.
- 3. Position the 'right hand' side guide on to the stacker bed leaving a minimum clearance of approximately 1mm each side of the sheet.



- 4. Whilst the sheet is between the two guides on the stacker bed, set the distance between the top of the sheet and the backstop flanges to approximately 5mm.
- 5. For shorter sheets, the back stop can be used (as shown in FIG 13.1) to adjust the position of the paper stack.



<u>TIPS</u>

L

L

- One of the back stops supplied with the machine (on the stacker assembly) can also be used as a tool holder as demonstrated in the photograph (left).
 - The scale on the bed can be used to measure the desired creasing or perforating position on the sheet.

Note

Perforating and creasing can be carried out simultaneously. However, if any adjustment is made to the roller tilt mechanism in order to compensate for the perforation line being 'out of square', this may effect the accuracy of the crease. If this occurs creasing and perforating must be carried out as separate operations.

The components and tools required to install the perforator are contained in the despatch kit supplied with the machine, they are listed below.

1 off Set of standard perforation '56 tooth' blades.

- 1 off Set of standard hardened anvils.
- 1 off Perforator stripper.
- 1 off 3mm bondhus wrench / allen key
- 1 off 2mm bondhus wrench / allen key



The perforator blades are split into two matching halves and are fitted to the drive wheels as shown in the photograph using the four screws supplied.

A hardened anvil is fitted to the drive hub as shown in the photograph also using the four screws supplied. Again the anvils are made from matching halves.

Important: The perforator blades are very sharp and care must be taken whilst handling. Do not mix the matching pairs of blades or anvils.

Perforating 'Spares' kits

For perforating and other types of paper, various spares kits are available which can be assembled to the machine in the same fashion. They are listed below along with a range of scoring wheels,

Perforating blades	56 teeth	Part Number	1-99-41	-	Standard stock / fine perforations.
	28 teeth	Part Number	1-99-12	-	Medium stock / medium perforations.
	20 teeth	Part Number	1-99-10	-	Heavy stock / coarse perforations.
Anvils	Standard	Part Number	1-99-35	-	For all blade types


All of the blades and anvils are supplied with fixings.


*Perforator stripper Standard Part Number 78-013

*It is recommended that for multiple perforations, a separate perforator stripper is used for every perforating blade set fitted in the creasing unit.


Setting the machine

- 1. Turn the mains supply to the machine 'off'.
- 2. Remove the stacker unit and open the exit guard.
- 3. Locate and remove the blades / anvils from the despatch kit supplied with the machine.
- 4. Using the 2mm allen key (supplied), loosen the drive wheel that is to accommodate the blades.
- 5. Slide the drive wheel away from any obstructing drive wheels or hubs in order to mount the blades.





- 7. Mount the other matching pair to the drive wheel as shown (fig 16.1). Secure the blades to the wheel ensuring not to over tighten grub screw.
- 8. Mark on a single sheet the desired perforating position. Feed the sheet through the machine manually until the mark can be seen. Use this mark to assist in fixing the position of the perforating drive wheel to the roller drive shaft.



- 9. Using the 2mm allen key, loosen the drive hub nearest the perforating drive. Slide the drive hub away from any obstructing drive wheels or hubs in order to mount the anvils.
- 10. Using the 2.5mm allen key, take one of the matching pairs of anvils and mount to the drive hub. Do not secure the anvil.

SYSTEM


- 11. Mount the other anvil ensuring that they have matched on the drive hub. Secure the anvil to the hub ensuring not to over tighten grub screw as shown in fig 16.2.
- 12. Slide the drive hub towards the perforating drive wheel until there is a clearance of 0.5mm.
- 13. To prevent damage to the blades or the anvils, do not force the drive wheel against the hub.
- 14. Fix the perforator stripper adjacent to the drive wheel and blade as shown.
- 15. Operate the machine and test the perforations for form.

It is important that the drive hubs are arranged evenly across the width of the paper in order to reduce the risk of jamming.

For multiple perforations repeat the above procedure.

Shaft support blocks are mounted on the top and bottom shafts. If they are in a position that obstructs perforating, they can be slid along just enough to clear the hubs. They should be mounted as near to the centre of the machine as possible, to maximise support. The depth of perforation can be adjusted by first loosening the socket set screws, in the support block, with a 2.5mm allen key. Insert the 2.5mm allen key into the grub screw, push the allen key up to decrease the perforating depth or down to increase the depth of perforation. Re-tighten the socket set screws.


(Note. This adjustment can also be carried out on the bottom shaft)



- 1 Perforating drive wheel with mounted blades
- 2 Perforator stripper
- 3 Standard drive wheel
- 4 Drive wheel with mounted anvils

- 5 Standard drive hub
- 6 Upper shaft support block
- 7 Lower shaft support block
- 8 Grub screw

Always remove blades and anvils once the perforating operation has been completed to avoid marking on digital or delicate media.




Adjusting the blade alignment

It is extremely important that the blade and anvil assembly within the creasing unit is correctly aligned. Misalignment of the blade or anvil can lead to damaged profiles and subsequently poor quality creasing so it must, therefore, be corrected immediately. If the blade set is misaligned, the media being driven will be subject to scoring or even tearing at any point along the crease line. **Please note that to avoid damage to the blade set, adjustment should only be made in small increments.** The below sketch demonstrates how the blade alignment can be carried out.


Adjustment can be made at either of the blade or anvil. The two clearance holes positioned above the roller tilt mechanism are the front alignment (one for blade, one for anvil). The two holes are repeated on the back of the machine for the back alignment.

- 1. Remove the stacker unit from the machine
- 2. Unlock and centralise the roller tilt mechanism in order to locate the heads of the front alignment screws.
- 3. Using a 3mm allen key, loosen the cap head type locking screws located on the front face at both ends of the blade /anvil as shown below.
- 4. Using a 4mm allen key, locate the two front or back alignment screws in the side frame in order to adjust the blade / anvil.
- 5. The upper screw of the two, will adjust the upper blade / anvil whereas the lower screw will adjust the lower blade / anvil both in very small increments.
- 6. In order to obtain the required position, adjust either the blade or the anvil by a small amount and then operate the machine to test the form of the crease. Repeat the exercise until centralisation is located.
- 7. Using a 3mm allen key, lock the cap head type screws (as per step 3) on both the upper and lower blade / anvil.




- 1. Before removing the blade assembly, ensure that the lower blade / anvil is NOT at 'top dead centre', Switch the machine off.
- 2. Remove the stacker unit and lift the exit guard.





- 3. Using a 6mm allen key, loosen the socket head screws located inside the blade adjustment cams. Remove the screws and the blade adjustment cams.
- 4. Insert the blade extractor tools (70-055-01 & 70-055-02) into the holes in the adjustment links, as shown. Push downwards on the handles of the blade extractor tools to release the blade assembly from the power links.
- 5. Slide the blade assembly out of the creasing unit and lay it on a flat surface.
- Slide the adjustment links away from the dowels located in the ends of the blades / anvils as shown in the photograph (left)
- 7. Place the new blade set into position. Check that the eccentric shoulder bolts on the link plates have been positioned as shown in fig 20.1.
- (Upper blade / anvil only) Slide the adjustment links onto the dowels.




9. Slide the new blade set into the slots of the creasing unit as shown in fig. 21.1.



NOTE.

The blade set can be fitted with the ANVIL at the bottom or with the ANVIL at the top. The blade set is supplied from the factory with the ANVIL at the bottom as shown in FIG22A.

The blade set can be changed to have the ANVIL at the top (as shown in FIG22B), this can improve the repeatability of the fold relative to the crease for certain fold types or when using lighter stocks.



Locate the blade extractor tools into the holes in the adjustment links as shown. Pull the handles of the blade extractor tools upwards to engage the blade assembly back into the power links.

10. Set the cam graphics for both ends of the blade / anvil to their lowest point on the scale (ie. When the mark on the scale reaches the mark on cam holder) Fasten the socket head screws on the adjustment cams until they are tight.

- 11. Push the exit guard down and replace the stacker assembly before operating the machine.
- 12. Switch the machine on and test the crease for form.

If the pressure and the alignment of the crease is not to a satisfactory level, see pages 33 - 35 to adjust the creasing line.

'Spares' kits

In the event of any damaged or lost components within the blade assembly, spares kits are available on request. However, components within the blade set can not be ordered separately is single blade or anvil.

The following Blade sets are supplied with the Ω as $\hat{O} \in A$ tandard.

Standard Blade set

Consisting of a standard blade and anvil, blade brushes, blade links and alignment bolts.

When running lighter stocks it is recommended that an **Narrow Blade Set** is used, this can be purchased fro{ $\hat{A}OUUTOE'$

Paper crease out of square

- Check that the sheets are all square and exactly the same size before loading the stack on to the table.
- Check that the roller tilt mechanism is correctly set and locked in position.
- Check that the adjustable side lay has been correctly positioned ie. No further than 0.5mm from the paper stack.

Paper jamming

- Check that the leading edge of the paper is not being damaged by the paper gate. If this is occurring, check that the suction slot and the paper gate have been correctly set.
- Check that the first crease position is not too close to the leading edge of the paper. A minimum distance of 32mm is recommended.


Machine will not start

- Check the power supply to the machine.
- Check that the emergency stop button has been released.
- I Check that the exit guard is down.
- I Check that the stacker unit is located correctly and has not been disconnected from the magnetic switch.
- I Check that the lower blade / anvil is connecting to the home switch (mounted below the lower blade / anvil).

Paper not feeding

- Check that the paper stack is not too high or too heavy for the feeder. The height of the paper stack should be defined by the weight and the size of the stock being creased.
- I Ensure that the adjustable side lay is not pressed against the paper stack. However, if the clearance between the adjustable side lay and the paper stack is too great, the air supply will escape instead of blowing through the paper thus making it difficult to feed.
- I Check that the clearance between the paper gate and the suction roller is not set too low.
- I On digital media, the feeding performance may be improved if the leading edge of the stack is trimmed before loading onto the Machine.

- I Check that the air distribution has been correctly set.
- I Check that the air separation has been set high enough to feed the sheets.
- For heavy stocks, very small or very large sheets, embossed or even irregular stock, it may be required to feed the sheets manually see page 29 for instructions.




Machine not counting

Open the exit and remove the blade set (see pages 37-39) to access the dual sensor post located in between the drive rollers. Using a soft brush, clean the visible sensor on the end of the post. Use the brush to clean the sensors between the post and the bottom paper guide which are not visible. Photograph (left) shows the dual sensor post containing the sensors.

Paper jammed under paper gate.

If paper gets jammed under the paper gate the vacuum drum will stop rotating, this is a safety feature. Remove the paper and re-adjust the paper gate.



Error Screens (Continued)

Blade Not Home

If the machine stops and error message 04 is displayed on the touch screen, this indicates that the lower blade / anvil has not made contact with the HOME switch. i.e. blade still in top position. Switch the machine off and remove the blade set and ensure that the area is free from obstructions. Return the blade set to the creasing unit and switch the machine on. Operate the machine in the normal sequence, if the display continues to read error message 04 it is advised to contact a Service Engineer immediately.



Overlap

If the machine stops and error message 13 is displayed on the touch screen, this indicates that the 'Lead Edge Sensor' has seen a sheet subsequent to the first one as being longer. Again this could actually be a longer sheet, OR it could be a sensor problem (if it is a recurring problem). Check that the paper gate has been set correctly.




Lead Edge Sensor Blocked

If the machine stops and error message 60 is displayed on the touch screen, this indicates that the lead edge sensor is blocked.

Press the system switch down and then select the right or left arrows, to inch the paper forwards or backwards.

Press the green tick button and then press the start button.


This error message could also mean that the lead edge sensors are faulty or need cleaning.




Error Screens (Continued)

• Clean Lead Edge Sensor - Warning Screens.

1. The Clean Lead Edge Sensor warning screen, shown below, will appear when the Run button is pressed and the strength of the Lead Edge Sensor Beam is at about 50% (i.e. the slider is at about the mid-point position along the Indicator Scale).




2. The Clean Sensor, Error 65 warning screen, shown below, will appear if the strength of the Lead Edge Sensor Beam is allowed to get down to about 25%. The Lead Edge Sensors should ideally be cleaned before this warning screen appears.



NOTE.

The Lead Edge Sensors can be cleaned at any time by selecting the Tools Tab at the bottom of the Touchscreen and cleaning the Sensors as described on Pages 45 & 46.




SYSTEM

Page 45

Error Screens (Continued)

To clean the lead edge sensors open the exit guard to expose the blade set. Using the Sensor Cleaning Brush , supplied in the dispatch kit, insert

the brush between the blade brushes and the top and bottom blades to reach the upper and lower lead edge sensors. (See FIG.1 and FIG.2 below). Move the brush backwards and forwards several times across the sensors to clean them. Note the position of the slider on the indicator scale; the slider should have moved nearer to the top of the scale, indicating that dust has been removed from the sensors. This sensor cleaning operation can be repeated again to see if the sensor beam strength can be further improved. The Sensors can also be cleaned with a can of compressed air purchased from Farnell (Farnell Part No. 166-3191), or an equivalent product.



Recommended weekly operator maintenance

- I Clean all sensors
- Clean in feed rollers and output drive hubs using the cleaning kit provided (Cleaning kit part number 90-018)
- I Remove and clean the blade assembly
- I With the blade assembly removed, clean the slots and surrounding area within the creasing unit.

Technician Maintenance

It is recommended that your machine is fully serviced at least once every six months by a factory trained Service Engineer.

ITEM	PART NUMBER	QTY	DESCRIPTION	
1	70-171	1	OPERATORS MANUAL -	
2	90-018	1	ROLLER CLEANING KIT	
3	650-040	1	POWER CORD CE UK C19 3Pin 16A 2.5Mtrs.	
4	403-01-030-006	12	SCREW - SOCKET CAP HEAD - M3 x 6 LG	
5	409-01-040-004	1	SCREW - SKT. SET FLAT PT M4 x 4 LG	
		_		
6 7	620-007	1	HEXAGON BALL DRIVER 2mm	
	620-020	1	HEXAGON BALL DRIVER 2.5mm	
8	620-004	1	ALLEN KEY 4mm	
0	620-004		ALLEN KET 4000	
9	620-026	1	BONDUS L WRENCH 4mm	
10	620-028	1	BONDUS L WRENCH 3mm	
11	620-033	1	BONDUS L WRENCH 6mm	
12	624-018	1	DISPATCH BOX	
13	70-055-01	1	BLADE EXTRACTION TOOL - OP SIDE	
14	70-055-02	1	BLADE EXTRACTION TOOL - LAY SIDE	
15	08-041-02	1	SLITTING ANVIL - UNDERSIZE.	
16	1-99-12	1	SLITTER PERF BLADE 28T	

WARNING..... THE BLADES FOR ANVIL AND PERFORATING SETS ARE SUPPLIED AS MATCHING PAIRS AND SHOULD NOT BE MIXED OR LEFT UNPROTECTED OR SERIOUS DAMAGE MAY RESULT.

ITEM	PART NUMBER	DESCRIPTION
1	1-99-10	PERFORATING BLADE SET 20T (Card)
2	1-99-12	PERFORATING BLADE SET 28T (Single sheets)
3	1-99-41	PERFORATING BLADE SET 56T (Fine perforations)
4	1-99-35	ANVIL SET USED WITH ABOVE BLADE SETS
5	76-237-03	BLADE SET - NARROW
6	70-134	ANTI-STATIC KIT
7	172-04-01	NARROW SHEET KIT

ACCESSORIES.....

....May be obtained from your dealer and fitted to your machine using the instructions supplied, or by reading your operators manual.

OPTIONS....

....May also be obtained and fitted by your dealer. You should not attempt to fit options as specialist tools and knowledge are required.

RECOMMENDED SPARES

PART NUMBER	DESCRIPTION
93-021	FEED BELT
607-017	TIMING BELT - 120XL 037
609-011	'O' RING Ø20
94-028	LOCK PIN ASSEMBLY - Side Lay
613-365	EMERGENCY STOP SWITCH
652-011	SWITCH - LOW CURRENT COIL - BLACK ROCKER
75-500-06	MINI ITX MOTHERBOARD -
75-430-01	CONTROL PCB ASSEMBLY
174-06-01	SMALL STEPPER DRIVER - LOW POWER - PCB ASSY
174-19-01	RS232 ADAPTOR PCB ASSY
125-21-02	DUAL STEPPER DRIVER PCB ASSEMBLY
75-06-02	TOUCHSCREEN ASSY - 7" (NEW CONTROLLER)
76-272	PSU ASSEMBLY - ATX12V - 300W
655-015	PSU UNIT - SWITCH MODE - 24V
655-016	PSU UNIT - SWITCH MODE - 48V
76-230-02	PAPER GUIDE ASSEMBLY - Bottom Sensor
76-155	PAPER JAM SENSOR ASSEMBLY
76-154	UPPER SENSOR ASSEMBLY
76-156	BLADE POSITION SENSOR LEAD
98-013-03	ANTI-STATIC BRUSH
609-022	'O' RING Ø32
606-035	KNOB - Roller Tilt
76-109	POWER LINK BEARING
76-237-02	BLADE SET - Standard
76-042	DRIVE BELT - FEED BED
607-042	TIMING BELT 160XL
607-048	TIMING BELT TWIN GRIP - 200 DXL 050
608-019	SHOULDER BOLT
76-082	PERFORATOR - DRIVE HUB ASSEMBLY
76-083	PERFORATOR - DRIVE WHEEL
76-177-02	INPUT ROLLER - Upper
76-175-02	INPUT ROLLER - Lower
76-019-02 78-013	OUTPUT SHAFT - Wide
	PERFORATOR STRIPPER ASSEMBLY
613-351	MICRO SWITCH - Guard Circuit
613-191	MICRO SWITCH - Home Circuit


PART NUMBER	DESCRIPTION
75-040	STACKER SWITCH ASSEMBLY
602-056	BEARING-DRAWN CUP NEEDLE ROLLER-Ø15XØ21X12
602-085	BEARING-DRAWN CUP NEEDLE ROLLER Ø10XØ14X10
76-145-02	GAP CONTROL HUB - LAY SIDE
76-148-01	GAP SET LEVER ASSY - OP SIDE
76-148-02	GAP SET LEVER ASSY - LAY SIDE
76-149-01	LOCKING LINK - GAP CONTROL
76-150-01	LOCKING KNOB - GAP CONTROL
76-255	LEAD - FOLD COMPENSATION SENSOR
75-427	LEAD - VALVE SENSOR
609-024	'O' RING Ø6 x Ø2.5
175-28-01	BUTTERFLY VALVE
76-240	STEPPER DRIVE MOTOR ASSEMBLY
76-241	STEPPER BLADE MOTOR ASSEMBLY
681-020	FUSE 500mA - Antl-surge
681-011	FUSE 315mA - Anti-surge
681-015	FUSE 4A - Anti-surge
652-047	FUSE 15A - Anti-surge
75-530-01	TRANSFORMER ASSEMBLY 230V TO 110V

NOTE.....

The items listed above represent parts which are subject to wear, loss, or accidental damage, and is included for your guidance only.

Replacement of parts fitted to your machine require specialist knowledge and should therefore be entrusted to your dealer.

FUSE POSITIONS & RATINGS (POSITION ET CLASSIFICATION DES FUSIBLES)



PRODUCT RECYCLING & DISPOSAL

European Union

Disposal Information for Commercial Users



Application of this symbol on your equipment is confirmation that you must dispose of this equipment in compliance with agreed national Procedures.

In accordance with European legislation end of life electrical and electronic equipment subject to disposal must be managed within agreed procedures.

Prior to disposal please contact your local dealer or representative for end of life take back information.

Disposal Information for Domestic Users



Application of this symbol on your equipment is confirmation that you should not dispose of the equipment in the normal household waste stream.

In accordance with European legislation, end of life electrical and electronic equipment subject to disposal must be segregated from household waste.

Private households within EU Member States may return used electrical and electronic equipment to designated collection facilities free of charge. Please contact your local disposal authority for information.

In some Member States when you purchase new equipment your local retailer may be required to take back your old equipment free of charge. Please ask your retailer for information.

Other Countries

Please contact your local waste authorities and request disposal information.



REVISION HISTORY

Rev.	Mod No.	Mod Description	Date	Mod By
4	ECO2809	Screen shot graphics changed to show the Lead Edge Sensor Indicator	02/01/13	BAL
		Bar, on all relative pages. New pages inserted to describe how to use the		
		Cover Crease Mode for Perfect Bound Covers. (Pages 14 & 15). New		
		pages inserted to show the Clean Lead Edge Sensor Warning Screens		
		and how to clean the Lead Edge Sensors. (Pages 44 to 46)		