
Premier T12 SharpCut 12 Inch Guillotine Paper Trimmer

Instruction Manual






T12 PARTS LIST

	Part Number	Description	Qty.		Part Number	Description	Qty.
1	M-O017903	LEFT REAR BASE T12/15	1	8	M-S004019	POLY BLADE SCREW	6
2	M-S004078	8 X 7/8 PH PAN HD LR	6	9	W-O017812	12" BED BLADE	1
3	M-O017956	RIGHT REAR BASE T12/15	1	10	M-O017902	T12/15 RIGHT FOOT	1
4	M-S004065	#8X5/8 PH PAN HD B/O	1	11	M-S030010	T BUMPER (FOOT)	4
5	M-O017801	POLY ARM HAND GRIP	1	12	M-O017901	T12/15 LEFT FOOT	1
6	W-O017811	12" CURVED BLADE	1	13	M-S004052	#8 X 1/2 P/PH	2
7	W-O017814	FINGER GUARD, T12	1		•	•	

T15 PARTS LIST


	Part Number	Description	Qty.		Part Number	Description	Qty.
1	M-O017903	LEFT REAR BASE T12/15	1	8	M-S004019	POLY BLADE SCREW	8
2	M-S004078	8 X 7/8 PH PAN HD LR	6	9	W-O017822	15" BED BLADE	1
3	M-O017956	RIGHT REAR BASE T12/15	1	10	M-O017902	T12/15 RIGHT FOOT	1
4	M-S004065	#8X5/8 PH PAN HD B/O	1	11	M-S030010	T BUMPER (FOOT)	4
5	M-O017801	POLY ARM HAND GRIP	1	12	M-O017901	T12/15 LEFT FOOT	1
6	W-O017821	15" CURVED BLADE	1	13	M-S004052	#8 X 1/2 P/PH	2
7	W-O017824	FINGER GUARD, T15	1		•		

PremierSharpCut Paper Trimmers



Key Features and Benefits


- Heavy-duty 1/2" thick wood base
- Hardened self-sharpening stainless steel blades cut up to 15 sheets
- Permanent 1/2" grid and dual rulers for proper paper alignment
- Patented automatic blade latch locks with every cutting motion
- Finger guard helps protect the entire blade length
- Torsion spring counterbalances blade arm
- Non-skid feet



T12 - 12" cutting length

T15 - 15" cutting length





Key Components

A - Hand Grip

B - Blade Arm

C - Wood Base with Molded End Caps


D – Alignment Ruler

E - Finger Guard

F - Paper Guide Ruler

Assembly Instructions

- 1. Hold the top of the blade arm (B) with one hand, being careful not to touch the blade, and the hand grip (A) with the other hand.
- 2. Slide the hand grip (A) onto the blade arm (B). The tab on the blade arm (B) should snap firmly into the notch on the hand grip (A).
- 3. Place the rubber feet into position on the bottom of the trimmer.



Operating Instructions

- 1. Place the trimmer on a flat, stable surface
- 2. Release the blade latch, which is located on the hand grip (A)
- 3. Lift the blade arm (B) up into cutting position
- 4. Using the rulers or the 1/2" grid, align the paper to the proper position, pushing it up against the paper guide ruler (F).

CAUTION:

Keep hands and fingers behind the finger guard (E) at all times, away from the cutting blades

- 5. While holding the paper down with your left hand (to make sure it stays in place), pull down the blade arm (B) to cut.
- 6. Always make sure that the blade arm is completely down and locked when not in use.

Safety Information

- Always ensure that the blade arm is fully pushed down, and that the blade latch is engaged, when not in use
- · Never operate the trimmer without the finger guard in place
- Always keep clothing, jewelry, watches, and hair away from the cutting blade
- Keep out of the reach of children
- Do not carry the trimmer by the hand grip or the blade arm

For Best Cutting Performance

Use Trim-Ease Blade Lubricant for a smoother cut and to help preserve the life of the cutting blade. To order, send \$4.00 per stick and a self-addressed, stamped envelope to the address below.

<u>Customer Service</u>

Telephone: (260) 563-0641 **Fax**: (260) 563-4575

Email: info@martinyale.com
Internet: www.martinyale.com
Address: Martin Yale Industries, Inc.

251 Wedcor Avenue Wabash, IN 46992

Visit www.martinyale.com for information on office products, including paper folding machines, punches, letter openers, catalog racks, and computer keyboard drawers.