

***H. Wilson WT34GYC4E-N
Gray 34" High Tuffy Utility
A/V Cart with Cabinet
(3-Shelf Nickel Legs)***

Instruction Manual



Provided by

MyBinding.com
When Image Matters.

Call Us at 1-800-944-4573


Parts List

Tools Required

- Rubber Mallet

NOTICE:


Leg lengths of leg **E** may be shorter than leg **F**



E x4

F x4


Optional fluted legs for units with cabinet pack



A x1


C x1

B x1




D x4

1




2


Install optional cabinet pack / pullout shelf / locking drawer assembly after step 1




3



4




5



6



Parts List




Tools Required

- Rubber Mallet


Tuffy Cart Cabinet Pack Instructions

Please consult your Tuffy cart base unit instructions before starting


- 1** **IMPORTANT:** Flip shelf **B**, and lock the 2 locking casters **D** before assembling the unit.




2




3




4




5



6




Parts List




Tools Required

- Screwdriver




C x2



D x2

Electric Assembly Instructions

Number of outlets may vary.



1

Push screw **C** through electric outlet **A**. Make sure the electric outlet **A** and cord wrap **B** align with the mounting surface screw holes. Push screw **C** through cord wrap **B** and the mounting surface screw holes. Use wing nut **D** and screwdriver to fasten.