



210PB

## 210PB COMBO MENU

DRAWING NO	PART NO	DESCRIPTION	DRAWING NO	PART NO	DESCRIPTION
101	A-1AA	BASE BOARD	130	FD-38	BUSH
103	A-2A	COVER PLATE<LEFT>	131	I-10	TUBE
104	A-3A	COVER PLATE<RIGHT>	132	NH-B1	ADJUSTMENT PLATE
105	B-1	WASTER DRAWER	133	NH-B2	SET-PIN GUIDER
106	B-2	PLASTIC HOLDER	134	NH-B2A	SET-PIN GUIDER
107	B-3	KNOB <LEFT>	135	NH-D3	STOP GUIDE AXLE
108	B-4A	KNOB <RIGHT>	136	NH-D4A	GUIDE PLATE
109	B-5	WEDGE	137	NH-D6A	BRACKET
110	B-9	RUBBER FOOT	138	NH-D8B	SET-PIN
111	BA-4A	HANDLE	139	NH-D10	BEARING BRACKET <LEFT>
112	CB-3	PAPER STOP SCREW	140	NH-D11	BEARING BRACKET <RIGHT>
113	CB-4	PAPER STOP GUIDE	141	NH-D15	RACK
114	CB-5	PAPER STOP NUT	142	NH-D18B	KNIFE SET PLATE <UPPER>
115	CD-25A	PAPER STOP RAIL COMPLET	143	NH-D18B-1B	KNIFE SET PLATE <LOWER>
115-1	C-1	ALIGNMENT SCALE	144	NH-D18-1A	KNIFE PAD
116	D-1A	BAKE COVER	145	NH-K1	
117	D-2A	FRONT PLATE	146	PD-19-1C	KNIFE
118	D-3	COVER PLATE	147	NH-D19B	TRANSMISSION PLATE<RIGHT>
119	D-7	RAKE	148	NH-D19B-1	TRANSMISSION PLATE<LEFT>
120	D-8	PLATE	149	NH-D35	ADJUSTMENT AXLE
121	D-19T	SWING PLATE	150	NH-D35-1A	ADJUSTMENT PLATE
122	D-20-1	SPACER	150-1	NH-D35-1	
123	D-20-2	WASHER	151	NH-D36A	ADJUSTMENT BRACKET
124	D-21A	HINGE COMPLET <RIGHT>	152	TB-11	AXLE CAP
125	D-21A-1		153	TC-8	CARRIER
126	D-22AA	AXLE	154	TC-16A	SLIDE
127	D-35A	SPRING	155	3LM-B4-1	GEAR
128	FD-13	TOOTH SEGMENT	157	C-2	MARK
129	FD-32	W TYPE SPRING			