

Coverbind 5000 / Bindomatic Accel Flex Professional Thermal Binding Machine

Instruction Manual



Provided by

MyBinding.com
When Image Matters.

Call Us at 1-800-944-4573

COVERBIND®

BINDING EFFICIENCY EXPERTS

Overview

The Accel Flex is a manually-operated tabletop binding machine that provides quick turnaround time when you need it. This versatile unit has an open heating element for binding larger documents, measuring up to 14" long and 2" wide, or multiple smaller documents at the same time providing exceptional binding capacity.

How to use the Accel Flex

Making a professional impression is simple. Create a perfect-bound or soft or hard cover book with the Accel Flex using these simple steps:



1. Determine the cover spine width you will need for your document by placing all pages of the document being bound in the cover size selector.



2. Insert the document in the appropriate Coverbind cover, making sure all pages are aligned correctly.



3. Bind one or several documents at a time by placing the cover spine side down on the heating plate.



4. Wait for the machine to signal that the thermal binding process is complete. Remove the bound books from the heating plate. Allow the finished books to rest spine side down in the cooling rack for two minutes before opening.



Congratulations! You have produced a professionally-bound document in a matter of minutes.

** Please note there is no power switch. Machine will go into a standby mode until document is inserted into the machine.*