

***H. Wilson WT34BUC4E-N
Blue 34" High Tuffy Utility
A/V Cart with Cabinet
(3-Shelf Nickel Legs)***

Instruction Manual



Provided by
MyBinding.com
When Image Matters.

Call Us at 1-800-944-4573



Parts List

Tools Required


- Rubber Mallet

NOTICE:

Leg lengths of leg **E** may be shorter than leg **F**



Parts List



Tools Required


- Rubber Mallet

Tuffy Cart Cabinet Pack Instructions


Please consult your Tuffy cart base unit instructions before starting

1


IMPORTANT: Flip shelf **B**, and lock the 2 locking casters **D** before assembling the unit.




2




3




4



5



6





Parts List

Tools Required

- Screwdriver

Electric Assembly Instructions

Number of outlets may vary.



1

Push screw **C** through electric outlet **A**. Make sure the electric outlet **A** and cord wrap **B** align with the mounting surface screw holes. Push screw **C** through cord wrap **B** and the mounting surface screw holes. Use wing nut **D** and screwdriver to fasten.