

***H. Wilson WT34C4E-N Black 34"  
High Tuffy Utility A/V Cart with  
Cabinet (3-Shelf Nickel Legs)***

**Instruction Manual**



*Provided by*

**MyBinding.com**  
*When Image Matters.*

**Call Us at 1-800-944-4573**



Parts List

Tools Required


- Rubber Mallet

NOTICE:

Leg lengths of leg **E** may be shorter than leg **F**



## Parts List



## Tools Required


- Rubber Mallet

## Tuffy Cart Cabinet Pack Instructions


Please consult your Tuffy cart base unit instructions before starting

1


**IMPORTANT:** Flip shelf **B**, and lock the 2 locking casters **D** before assembling the unit.




2




3




4



5



6





## Parts List

## Tools Required

- Screwdriver

## Electric Assembly Instructions

Number of outlets may vary.



1

Push screw **C** through electric outlet **A**. Make sure the electric outlet **A** and cord wrap **B** align with the mounting surface screw holes. Push screw **C** through cord wrap **B** and the mounting surface screw holes. Use wing nut **D** and screwdriver to fasten.