H. Wilson WT34GC2E-B Green 34" High Tuffy Utility A/V Cart with Cabinet (3-Shelf Black Legs)

Instruction Manual



Call Us at 1-800-944-4573


LUXOR H.WILSON

3 Shelf Tuffy Cart Instructions


NOTICE: Leg lengths of leg E may be shorter than leg F Optional fluted legs for units with



E ×4




Install optional cabinet pack / pullout shelf / locking drawer assembly after step 1




3

BX1




4



5

cabinet pack

F ×4




6



LUXOR H.WILSON

Tuffy Cart Cabinet Pack Instructions

Please consult your Tuffy cart base unit instructions before starting





Tools Required

- Rubber Mallet




IMPORTANT: Flip shelf **B**, and lock the 2 locking casters **D** before assembling the unit.







2








3



6



LUXOR H.WILSON

Electric Assembly

Parts List A X1 B X1

Tools Required

- Screwdriver





Number of outlets may vary.

Instructions

