H. Wilson 42" High Blue Tuffy Utility A/V Cart with Cabinet and Pullout Shelf (3-Shelf Nickel Legs)





Call Us at 1-800-944-4573

LUXOR H.WILSON

3 Shelf Tuffy Cart Instructions

Call Us at 1-800-944-4573 for Orders or Inquiries


NOTICE:


Leg lengths of leg **E** may be shorter than leg **F**


Parts List

Tools Required

- Rubber Mallet

















Install optional cabinet pack / pullout shelf / locking drawer assembly after step 1








4



5



6



LUXOR H.WILSON

Front Pullout Shelf Instructions

Tuffy Cart


Call Us at 1-800-944-4573 for Orders or Inquiries

Parts List

Tools Required

- Phillips Screwdriver















1 **K** ×1

Lay the top shelf of your Tuffy cart upside down and Install the four legs intended for this shelf.



Slide and align runner **H** & **G** onto the legs and tighten screw **N** with a screwdriver.







Take pullout shelf **K** and bracket **L** and screw together into the unfinished surface of shelf **K** with screw **M**.



Mount pullout shelf ${\bf K}$ to runner ${\bf H}$ & ${\bf G}$ so that the edge of the shelf snaps into the runner hooks.





You have now completed your pullout shelf.