H. Wilson 42" High Black Tuffy Utility A/V Cart with Pullout Shelf (3-Shelf Nickel Legs)

Instruction Manual



Call Us at 1-800-944-4573

LUXOR H.WILSON

3 Shelf Tuffy Cart Instructions


Call Us at 1-800-944-4573 for Orders or Inquiries

Parts List


Tools Required

- Rubber Mallet

NOTICE:




F ×4









E ×4




Install optional cabinet pack / pullout shelf / locking drawer assembly after step 1








4



5



6



LUXOR H.WILSON

Front Pullout Shelf Instructions

Tuffy Cart


Call **Us at**1-800-944-4573
for Orders or Inquiries

Parts List

Tools Required

- Phillips Screwdriver

 $\mathbf{G} \times 1$













Lay the top shelf of your Tuffy cart upside down and Install the four legs intended for this shelf.



Slide and align runner **H** & **G** onto the legs and tighten screw **N** with a screwdriver.







Take pullout shelf **K** and bracket **L** and screw together into the unfinished surface of shelf **K** with screw **M**.



Mount pullout shelf **K** to runner **H** & **G** so that the edge of the shelf snaps into the runner hooks.






You have now completed your pullout shelf.

LUXOR H.WILSON

Electric Assembly Instructions

Number of outlets may vary.



Tools Required

- Screwdriver





