H. Wilson 42" High Green Tuffy Utility A/V Cart with Cabinet and Pullout Shelf (3-Shelf Nickel Legs)

Instruction Manual



Call Us at 1-800-944-4573

LUXOR H.WILSON


3 Shelf Tuffy Cart Instructions

Call Us at 1-800-944-4573 for Orders or Inquiries


Parts List

Tools Required


- Rubber Mallet









Install optional cabinet pack / pullout shelf / locking drawer assembly after step 1




3



4



5



6



LUXOR H.WILSON

Front Pullout Shelf Instructions

Tuffy Cart

Call Us at 1-800-944-4573 for Orders or Inquiries

Parts List

Tools Required

- Phillips Screwdriver









L X2




M ×6




N ×4


Lay the top shelf of your Tuffy cart upside down and Install the four legs intended for this shelf.



Slide and align runner **H** & **G** onto the legs and tighten screw **N** with a screwdriver.



- Take pullout shelf **K** and bracket **L** and screw together into the unfinished surface of shelf **K** with screw **M**.
- K L M
- Mount pullout shelf **K** to runner **H** & **G** so that the edge of the shelf snaps into the runner hooks.



You have now completed your pullout shelf.