H. Wilson 42" High Green Tuffy Utility A/V Cart with Pullout Shelf (3-Shelf Putty Legs)

Instruction Manual




Call Us at 1-800-944-4573

LUXOR H.WILSON

<u>3 Shelf Tuffy Cart Instructions</u>

Call Us at 1-800-944-4573 for Orders or Inquiries




LUXOR H.WILSON


Front Pullout Shelf Instructions

Tuffy Cart

1-800-944-4573 for Orders or Inquiries

Call Us at






Parts List



Tools RequiredPhillips Screwdriver



Lay the top shelf of your Tuffy cart upside down and Install the four legs intended for this shelf.



M x6


Slide and align runner H & G onto the legs

and tighten screw **N** with a screwdriver.

4

2


Mount pullout shelf **K** to runner **H** & **G** so that the edge of the shelf snaps into the runner hooks.



Take pullout shelf **K** and bracket **L** and screw

together into the unfinished surface of shelf K

with screw M.



You have now completed your pullout shelf.