H. Wilson 42" High Gray Tuffy Utility A/V Cart with Cabinet and Pullout Shelf (3-Shelf Black Legs)

Instruction Manual



Call Us at 1-800-944-4573

LUXOR H.WILSON


3 Shelf Tuffy Cart Instructions

Call Us at 1-800-944-4573 for Orders or Inquiries


Parts List

Tools Required


- Rubber Mallet









Install optional cabinet pack / pullout shelf / locking drawer assembly after step 1




3



A



5



6



LUXOR H.WILSON

Front Pullout Shelf Instructions

Tuffy Cart

Call Us at 1-800-944-4573 for Orders or Inquiries

Parts List

Tools Required

- Phillips Screwdriver
















Lay the top shelf of your Tuffy cart upside down and Install the four legs intended for this shelf.




Slide and align runner H & G onto the legs and tighten screw N with a screwdriver.



Take pullout shelf **K** and bracket **L** and screw together into the unfinished surface of shelf K with screw M.



Mount pullout shelf K to runner H & G so that the edge of the shelf snaps into the runner hooks.



You have now completed your pullout shelf.