H. Wilson 42" High Red Tuffy Utility A/V Cart with Pullout Shelf (3-Shelf Nickel Legs)

Instruction Manual




Call Us at 1-800-944-4573

LUXOR H.WILSON

<u>3 Shelf Tuffy Cart Instructions</u>

Call Us at 1-800-944-4573




LUXOR H.WILSON

Front Pullout Shelf Instructions


Tuffy Cart

Call Us at 1-800-944-4573 for Orders or Inquiries



8

with screw M.



Parts List




Tools Required

- Phillips Screwdriver



Lay the top shelf of your Tuffy cart upside down and Install the four legs intended for this shelf.



M x6


Slide and align runner H & G onto the legs

and tighten screw **N** with a screwdriver.

4


2

Mount pullout shelf **K** to runner **H** & **G** so that the edge of the shelf snaps into the runner hooks.



Take pullout shelf **K** and bracket **L** and screw

together into the unfinished surface of shelf K



You have now completed your pullout shelf.

LUXOR H.WILSON

