

DUST COVER TRIMMER

Operating Instructions

Blade install: (Fig. 1)

1. Determine right hand or left hand usage.
2. Remove nut and three (3) blades.
3. Separate and install one blade, sharp edge down.
4. Slide cover to "safe" when not using and "blade" when ready to use.

Apply dust cover:

1. Using double sided tape , ATG tape or glue, apply continuous line around back of frame about 1/8" from edge **(Fig. 2)**
2. Cut a piece of Kraft paper (30, 40, or 50 lb available at craft stores) that is larger than overall outside of frame by a minimum of 1".
3. Lay paper flat onto table and drop the frame straight down onto the paper with taped side down and artwork side facing up. **(Fig. 3)**
4. Using water in a spray bottle, completely dampen Kraft paper evenly. As water dries, the paper will shrink tight. **(Fig. 4)** **NOTE:** Use a hairdryer to decrease drying time.
5. Crease paper along the edges of frames **(Fig. 5)**
6. Using trimmer, start beyond edge of a corner, hold on slight angle up against frame edge. Draw trimmer along edge to trim. **(Fig. 6)**
7. Repeat for other three sides.

