Luxor Adjustable Height Black Steel A/V Cart with Pullout Keyboard Tray and Cabinet

Instruction Manual




Call Us at 1-800-944-4573

LUXOR

Pullout Keyboard Shelf Instructions

for Metal Carts

Parts List



Tools Required


- Phillips Screwdriver
- Pliers or Adjustable Wrench


















Collect parts: H. Align the pullout shelf H runner so that the runner snaps into place into the FL & FR brackets. Pull the shelf out to make sure it is fully seated. Tighten screws A and nut C. Pullout keyboard shelf assembly is now complete.

LUXOR

INNOVATIVE WORKSPACE PRODUCT SOLUTIONS

Adjustable Height
Metal Cart
Instructions




Tools Required


- Phillips Screwdriver
- Rubber Mallet
- Pliers or Adjustable Wrench
















Position the bottom shelf **B** so that the caster holes are facing up. Insert caster **C** into the caster holes on the bottom of shelf **B**. Use a mallet to set the casters properly.

2

Flip bottom shelf **B** so that it is on its side. Set top shelf **A** so that it overlaps bottom shelf **B**. Align the screw holes so that the top shelf **A** is at the desired height. 3

Insert screw **D** through the aligned screw hole of **A** and **B** and fasten nut **E** with pliers and screwdriver. Place Non-slip mat on desired shelf. The cart is now complete.

LUXOR

INNOVATIVE WORKSPACE PRODUCT SOLUTIONS

Electric Assembly Instructions

Number of outlets may vary.

