
Luxor RECLAIM Trifold 18" x 24" Clear Acrylic Freestanding Desk Shield


Instruction Manual



Call Us at 1-800-944-4573



- Attach 4 x C and 4 x D to Panel A with 8 x E using the included Allen wrench.
- Attach 4 x C and 4 x D to the 2 x Panel B with 8 x E using the included Allen wrench.



- Optional Remove film and attach 6 x F to 6 x G and attach 6 x G to the assembly.
- Assembly Complete The unit can be folded away for storage.