

# ***Luxor RECLAIM Trifold 58" x 24" Clear Acrylic Freestanding Desk Shield***

Instruction Manual



*Provided by*

**MyBinding.com**  
*When Image Matters.*





Call Us at 1-800-944-4573

## DIV3P Assembly Guide



Panel sizes will vary depending on model  
Remove protective film before assembly

### Tools Needed:

Allen Wrench (Included)



- 1 Attach 4 x C and 4 x D to Panel A with 8 x E using the included Allen wrench.
- 2 Attach 4 x C and 4 x D to the 2 x Panel B with 8 x E using the included Allen wrench.



- 3 Optional - Remove film and attach 6 x F to 6 x G and attach 6 x G to the assembly.
- 4 Assembly Complete - The unit can be folded away for storage.