Luxor LPDUOC-B Endura 24" x 18" Black Multi-Height A/V Utility Cart with Cabinet (No Outlet)

Instruction Manual



Call Us at 1-800-944-4573

Instruction Sheet - LP Model Tables Models LP-26 and LP-27 Two Shelf Mobile Tables Models LP-34, LP-40, LP-42, LP-48 and LP-54 Three Shelf Mobile Tables

Z: LUXOR

9620 NE Tanasbourne, Dr. Suite 250, Hillsboro, OR 97124

sales@mvbinding.com

1-800-944-4573





PARTS LIST

Models I P26 & I P27

- 1 Bottom shelf with casters sockets
- 1 Top shelf with handle
- 4 Long legs
- 4 Casters (2 w/brake)
- 1 Plug housing cover
- 2 Sheet metal screws

- Optional Electric Assembly: 1 - Electric cord
- 1 Power cord retaining bracket 1 - Cord tie
- 3 Sheet metal screws

Models I P34, I P40, I P42, LP48 & LP54

- 1 Bottom shelf with casters sockets
- 1 Top shelf with handle
- 1 Center shelf with eight leg posts
- 4 Short leas
- 4 Long legs
- 4 Casters (2 w/brake)
- 1 Plug housing cover
- 2 Sheet metal screws

Tools Required:


- 1 Rubber Mallet
- 1 Slotted Screwdriver

IMPORTANT:


If your LP table does not have the Optional Electrical Assembly start by closing the electric plug housing in the handle of the top shelf as illustrated. If your LP table has the Optional Electric Assembly, see assembly instructions below. Start by assembling electric.

MyBinding






RETAINING TRACK #2



Position bottom shelf, ribbed side up, over the 4 legs and insert leg posts into legs. Using a rubber mallet, firmly hammer bottom shelf into Lay top shelf (with handle) ribbed side up on a legs until all 4 legs are seated (flush) against the smooth surface. Push all 4 legs onto leg posts. surfaces of both shelves.



Push the four casters firmly into the holes in each corner of the bottom shelf. Important: Casters must be fully seated. Tap firmly with rubber mallet to properly seat casters. Turn your LP table right side up. It is now ready for use.

Models LP-34, LP-40, LP-42, LP-48 and LP-54


*Models LP34 and LP40 use short legs first. *Models LP42, LP48 and LP54 use long legs first.



Models LP-34 and LP-40: Lay top shelf (with handle) ribbed side up on a smooth surface. Push all 4 short legs onto leg posts.

Models LP-42, LP-48 and LP-54: Lay top shelf (with handle) ribbed side up on a smooth

surface. Push all 4 long legs onto leg posts.



POWER CORD

MANAGEMENT TIES

Firmly seat electrical assembly 3 plug unit into handle plug housing as illustrated. Secure with power cord plug retaining bracket. Thread cord through cord retaining track and out the opening in the side of the handle.


POWER CORD PLUG

RETAINING BRACKET

Secure power cord management tie into starter hole with sheet metal screws. See illustration A. Secure with power cord management tie by wrapping tie around cord and fastening. Cut off any unnecessary extra length of tie.




Position center shelf (with 8 leg posts) ribbed side up, over the 4 legs and insert leg posts into legs. Using a rubber mallet, firmly hammer center shelf into legs until all 4 legs are seated (flush) against the surfaces of both shelves.



Push remaining 4 legs into leg posts of center shelf.



Position bottom shelf, ribbed side up, over the 4 legs and insert leg posts into legs. Using a rubber mallet, firmly hammer bottom shelf into legs until all 4 legs are seated (flush) against the surfaces of both shelves.



Push the four casters firmly into the holes in each corner of the bottom shelf. Important: Casters must be fully seated. Tap firmly with rubber mallet to properly seat casters. Turn your LP table right side up. It is now ready for



For safety and neat appearance secure cord plug to cord by utilizing plug snap.