Luxor 32" Pneumatic Height Adjustable Café White Round Table - LX-PNADJ-32RD

Instruction Manual





Call Us at 1-800-944-4573


LUXOR INNOVATIVE WORKSPACE PRODUCT SOLUTIONS


Pneumatic Height Adjustable Circular Table


LX-PNADJ-SQ








































Lay Tabletop K on a clean stable flat surface. Take Center Pneumatic Pole L and lay the top (top side has the pneumatic hand lever) onto Tabletop K so that the holes match up for the Center Pneumatic Pole and the Pneumatic Handle as shown below.

Use Allen Wrench J to secure the center of Part L to Part K using four of Screw A.



NOTE: Before securing the Pneumatic Handle in the next step, make sure that the connector cord is snapped into the bottom of the Pneumatic Hand Lever as shown. This ensures it will work properly when assembled.







Choose either the **Casters** or **Stationary Feet** to finish your table. If you chose Casters, please follow Step 5. If you chose the Stationary Feet, please follow step 6.



To attach the Casters to your table, start by taking Parts C, D and G. Note that Caster F has locks so it is suggested that you put them towards whichever side you would like to be the front for easier locking. Start by taking Split Washer C and placing it over the screw on Caster G. Once Split Washer C is on the Caster, place Washer D on top of that. Then put the Caster into the inner hole on Base M. Secure with Wrench H. Repeat with all remaining Casters.



C X4




















6

To attach Stationary Feet to finish your table, get Part B. Place Part B into the outer hole on Base M as shown below. Use your hand to tighten Part B until secure.

