



TCC-242 COMBO MENU

DRAWING NO	PART NO	DESCRIPTION	DRAWING NO	PART NO	DESCRIPTION
001	A-2AA	COVER PLATE<LEFT>	025	NH-D3	STOP GUIDE AXLE
002	A-3A	COVER PLATE<RIGHT>	026	NH-D4A	GUIDE PLATE
003	B-3	KNOB <LEFT>	028	NH-D6B	BRACKET
003-1	B-4	KNOB <RIGHT>	029	NH-D7A	SUB-AXLE
004	B-5	WEDGE	029-1	NH-D7-1A	FIXED PLATE
005	B-9	RUBBER FOOT	030	NH-D8B	SET-PIN
006	BA-4A	HANDLE	031	NH-D10A	SUPPORT BEARING BRACKET <LEFT>
007	CB-3	PAPER STOP SCREW	032	NH-D11A	SUPPORT BEARING BRACKET <RIGHT>
008	CB-4	PAPER STOP GUIDE	033	NH-D15B	RACK
009	CB-5	PAPER STOP NUT	034	NH-D18A	KNIFE SET PLATE <UPPER>
010	D-17A	SPRING	034-1	NH-D18-1	KNIFE SET PLATE <DOWN>
010-1	D-35A	SPRING	034-2	NH-D18-1A	KNIFE PAD
011	FD-13	TOOTH SEGMENT	034-A	NH-K	
012	FD-32	W TYPE SPRING	035	NH-D19A	TRANSMISSION PLATE
013	FD-38	BUSH	036	NH-D20	AXLE
014	HD-2A	FRONT PLATE	037	NH-D35	ADJUSTMENT AXLE
015	HD-3	COVER PLATE	037-1	NH-D35-1	ADJUSTMENT PLATE
016	KC-8	CARRIER	038	NH-D36	ADJUSTMENT BRACKET
017	KC-16	SLIDE	039	PB-1	WASTER DRAWER
018	3LM-B4-1	GEAR	040	PD-1A	BAKE COVER
019	MD-7	RAKE	041	PD-10	PAPER STOP RAIL COMPLET
020	MD-8	PLATE	042	PD-19-1	KNIFE
021	NH-A1	BASE BOARD	043	TB-6	SPACER
022	NH-B1	GUIDE PLATE	044	TB-8	BUSH
023	NH-B2A	SET-PIN GUIDER	045	TB-11	AXLE CAP
024	NH-B3	SUB-HANDLE	046	B-2	PLASTIC HOLDER

